

This manual should be considered a permanent part of the motorcycle and should remain with the motorcycle when it is resold.

This publication includes the latest production information available before printing. Honda Motor Co., Ltd. reserves the right to make changes at any time without notice and without incurring any obligation.

No part of this publication may be reproduced without written permission.

The vehicle pictured in this owner's manual may not match your actual vehicle.

## Welcome

Congratulations on your purchase of a new Honda motorcycle. Your selection of a Honda makes you part of a worldwide family of satisfied customers who appreciate Honda's reputation for building quality into every product.

To ensure your safety and riding pleasure:

- Read this owner's manual carefully.
- Follow all recommendations and procedures contained in this manual.
- Pay close attention to safety messages contained in this manual and on the motorcycle.

- The following codes in this manual indicate each country.
- The illustrations here in are based on the VFR800X II ED type.

### Country Codes

Code	Country
<b>VFR800X</b>	
II ED	European direct sales South Africa, UK, France
II U	Australia, New Zealand

\*The specifications may vary with each locale.

## A Few Words About Safety

Your safety, and the safety of others, is very important. Operating this motorcycle safely is an important responsibility.

To help you make informed decisions about safety, we have provided operating procedures and other information on safety labels and in this manual. This information alerts you to potential hazards that could hurt you or others.

Of course, it is not practical or possible to warn you about all hazards associated with operating or maintaining a motorcycle. You must use your own good judgement.

You will find important safety information in a variety of forms, including:

- Safety labels on the motorcycle.
- Safety Messages preceded by a safety alert symbol and one of three signal words: DANGER, WARNING, or CAUTION.

These signal words mean:

### **DANGER**

You **WILL** be **KILLED** or **SERIOUSLY HURT** if you don't follow instructions.

### **WARNING**

You **CAN** be **KILLED** or **SERIOUSLY HURT** if you don't follow instructions.

### **CAUTION**

You **CAN** be **HURT** if you don't follow instructions.

**Other important information is provided under the following titles:**

**NOTICE** Information to help you avoid damage to your motorcycle, other property, or the environment.

# Contents

**Motorcycle Safety** P. 2

**Operation Guide** P. 18

**Maintenance** P. 51

**Troubleshooting** P. 97

**Information** P. 116

**Specifications** P. 130

**Index** P. 133

# Motorcycle Safety

This section contains important information for safe riding of your motorcycle.  
Please read this section carefully.

<b>Safety Guidelines</b> .....	P. 3
<b>Image Labels</b> .....	P. 6
<b>Safety Precautions</b> .....	P. 11
<b>Riding Precautions</b> .....	P. 12
<b>Accessories &amp; Modifications</b> .....	P. 16
<b>Loading</b> .....	P. 17

## Safety Guidelines

### Safety Guidelines

Follow these guidelines to enhance your safety:

- Perform all routine and regular inspections specified in this manual.
- Stop the engine and keep sparks and flame away before filling the fuel tank.
- Do not run the engine in enclosed or partly enclosed areas. Carbon monoxide in exhaust gases is toxic and can kill you.

#### Always Wear a Helmet

It's a proven fact: helmets and protective apparel significantly reduce the number and severity of head and other injuries. So always wear an approved motorcycle helmet and protective apparel.  P. 11

#### Before Riding

Make sure that you are physically fit, mentally focused and free of alcohol and drugs. Check

that you and your passenger are both wearing an approved motorcycle helmet and protective apparel. Instruct your passenger on holding onto the grab rails, leaning with you in turns, and keeping their feet on the footpegs, even when the motorcycle is stopped.

#### Take Time to Learn & Practice

Even if you have ridden other motorcycles, practice riding in a safe area to become familiar with how this motorcycle works and handles, and to become accustomed to the motorcycle's size and weight.

#### Ride Defensively

Always pay attention to other vehicles around you, and do not assume that other drivers see you. Be prepared to stop quickly or perform an evasive maneuver.

## Safety Guidelines

### Motorcycle Safety

#### Make Yourself Easy to See

Make yourself more visible, especially at night, by wearing bright reflective clothing, positioning yourself so other drivers can see you, signaling before turning or changing lanes, and using your horn when necessary.

#### Ride within Your Limits

Never ride beyond your personal abilities or faster than conditions warrant. Fatigue and inattention can impair your ability to use good judgement and ride safely.

#### Don't Drink and Ride

Alcohol and riding don't mix. Even one alcoholic drink can reduce your ability to respond to changing conditions, and your reaction time gets worse with every additional drink. Don't drink and ride, and don't let your friends drink and ride either.

#### Keep Your Honda in Safe Condition

It's important to keep your motorcycle properly maintained and in safe riding condition. Inspect your motorcycle before every ride and perform all recommended maintenance. Never exceed load limits (➤ P. 17), and do not modify your motorcycle or install accessories that would make your motorcycle unsafe (➤ P. 16).

#### If You are Involved in a Crash

Personal safety is your first priority. If you or anyone else has been injured, take time to assess the severity of the injuries and whether it is safe to continue riding. Call for emergency assistance if needed. Also follow applicable laws and regulations if another person or vehicle is involved in the crash.

If you decide to continue riding, first evaluate the condition of your motorcycle. If the engine is still running, turn it off. Inspect for fluid leaks,

## Safety Guidelines

check the tightness of critical nuts and bolts, and check the handlebar, control levers, brakes, and wheels. Ride slowly and cautiously. Your motorcycle may have suffered damage that is not immediately apparent. Have your motorcycle thoroughly checked at a qualified service facility as soon as possible.

### Carbon Monoxide Hazard

Exhaust contains poisonous carbon monoxide, a colourless, odorless gas. Breathing carbon monoxide can cause loss of consciousness and may lead to death.

If you run the engine in a confined or even partly enclosed area, the air you breathe could contain a dangerous amount of carbon monoxide. Never run your motorcycle inside a garage or other enclosure.

## WARNING

Carbon monoxide gas is toxic.  
Breathing it can cause  
unconsciousness and even kill you.

Avoid any areas or activities that  
expose you to carbon monoxide.

Motorcycle Safety

## Image Labels

# Image Labels

Motorcycle Safety

The following pages describe the label meanings. Some labels warn you of potential hazards that could cause serious injury. Others provide important safety information. Read this information carefully and don't remove the labels.

If a label comes off or becomes hard to read, contact your dealer for a replacement.

There is a specific symbol on each label. The meanings of each symbol and label are as follows.



Read instructions contained in Owner's Manual carefully.



Read instructions contained in Shop Manual carefully. In the interest of safety, take the motorcycle to be serviced only by your dealer.

### **DANGER (with RED background)**

You **WILL** be **KILLED** or **SERIOUSLY HURT** if you don't follow instructions.

### **WARNING (with ORANGE background)**

You **CAN** be **KILLED** or **SERIOUSLY HURT** if you don't follow instructions.




### **CAUTION (with YELLOW background)**

You **CAN** be **HURT** if you don't follow instructions.

Image Labels

Motorcycle Safety



**BATTERY LABEL**

**DANGER**

- Keep flame and spark away from the battery. Battery produce explosive gas that can cause explosion.
- Wear the eye protection and rubber gloves when handling the battery, or you can get burned or lose your eyesight by the battery electrolyte.
- Do not allow children and other people to touch a battery unless they understand proper handling and hazards of the battery very well.
- Handle the battery electrolyte with extreme care as it contains dilute sulfuric acid. Contact with your skin or eyes can burn you or cause loss of your eyesight.
- Read this manual carefully and understand it before handling the battery. Neglect of the instructions can cause personal injury and damage to the motorcycle.
- Do not use a battery with the electrolyte at or below the lower level mark. It can explode causing serious injury.

*continued* 7

## Image Labels

Motorcycle Safety




### RADIATOR CAP LABEL DANGER

NEVER OPEN WHEN HOT.

Hot coolant will scald you.

Relief pressure valve begins to open at **108 kPa**.



### ACCESSORIES AND LOADING WARNING LABEL WARNING

ACCESSORIES AND LOADING

- The safety stability and handling of this motorcycle may be affected by the addition of accessories and luggage.
- Read carefully the instructions contained in user's manual and installation guide before installing any accessory.
- The total weight of accessories and luggage added to rider's and passenger's weight should not exceed **192 kg (423 lb)**, which is the maximum weight capacity.
- The luggage weight must not exceed **18 kg (40 lb)** under any circumstances.
- The fitting of large fork-mounted or large handlebar mounted fairing is not recommended.

Image Labels

Motorcycle Safety



### REAR CUSHION LABEL

GAS FILLED

Do not open. Do not heat.

### TYRE INFORMATION LABEL

Cold tyre pressure:

[Driver only]

Front **250 kPa (2.50 kgf/cm<sup>2</sup>, 36 psi)**

Rear **290 kPa (2.90 kgf/cm<sup>2</sup>, 42 psi)**

[Driver and passenger]

Front **250 kPa (2.50 kgf/cm<sup>2</sup>, 36 psi)**

Rear **290 kPa (2.90 kgf/cm<sup>2</sup>, 42 psi)**

Tyre size:

Front **120/70R17M/C 58V**

Rear **180/55R17M/C 73V**

Tyre brand: PIRELLI

Front **SCORPION TRAIL**

Rear **SCORPION TRAIL**



continued 9

## Image Labels

Motorcycle Safety



### **SAFETY REMINDER LABEL**

For your protection, always wear helmet, protective apparel.

### **FUEL LABEL**

Unleaded petrol only



### **DRIVE CHAIN LABEL**

Keep chain adjusted and lubricated.

**30 to 40 mm (1.2 to 1.6 in)** Freeplay

## Safety Precautions

### Safety Precautions

- Ride cautiously and keep your hands on the handlebar and feet on the footpegs.
- Keep passenger's hands onto the grab rails, passenger's feet on the footpegs while riding.
- Always consider the safety of your passenger, as well as other drivers and riders.

#### Protective Apparel

Make sure that you and any passenger are wearing an approved motorcycle helmet, eye protection, and high-visibility protective clothing. Ride defensively in response to weather and road conditions.

#### Helmet

Safety-standard certified, high-visibility, correct size for your head.

- Must fit comfortably but securely, with the chin strap fastened.

- Face shield with unobstructed field of vision or other approved eye protection.

#### **⚠ WARNING**

Not wearing a helmet increases the chance of serious injury or death in a crash.

Make sure that you and any passenger always wear an approved helmet and protective apparel.

#### Gloves

Full-finger leather gloves with high abrasion resistance.

#### Boots or Riding Shoes

Sturdy boots with non-slip soles and ankle protection.

#### Jacket and Trousers

Protective, highly visible, long-sleeved jacket and durable trousers for riding (or a protective suit).

## Riding Precautions

# Riding Precautions

Motorcycle Safety

### Running-in Period

During the first 500 km (300 miles) of running, follow these guidelines to ensure your motorcycle's future reliability and performance.

- Avoid full-throttle starts and rapid acceleration.
- Avoid hard braking and rapid down-shifts.
- Ride conservatively.

### Brakes

Observe the following guidelines:

- Avoid excessively hard braking and down-shifts.
  - ▶ Sudden braking can reduce the motorcycle's stability.
  - ▶ Where possible, reduce speed before turning; otherwise you risk sliding out.
- Exercise caution on low traction surfaces.
  - ▶ The tyres slip more easily on such surfaces and braking distances are longer.
- Avoid continuous braking.
  - ▶ Repeated braking, such as when descending long, steep slopes can seriously overheat the brakes, reducing their effectiveness. Use engine braking with intermittent use of the brakes to reduce speed.
- For full braking effectiveness, operate both the front and rear brakes together.

## Riding Precautions

### ■ Anti-lock Brake System (ABS)

This model is equipped with an Anti-lock Brake System (ABS) designed to help prevent the brakes from locking up during hard braking.

- ABS does not reduce braking distance. In certain circumstances, ABS may result in a longer stopping distance.
- ABS does not function at speeds below 10 km/h (6 mph).
- The brake lever and pedal may recoil slightly when applying the brakes. This is normal.
- Always use the recommended tyres to ensure correct ABS operation.

### ■ Engine Braking

Engine braking helps slow your motorcycle down when you release the throttle. For further slowing action, downshift to a lower gear. Use engine braking with intermittent use of the brakes to reduce speed when descending long, steep slopes.

### ■ Wet or Rainy Conditions

Road surfaces are slippery when wet, and wet brakes further reduce braking efficiency. Exercise extra caution when braking in wet conditions.

If the brakes get wet, apply the brakes while riding at low speed to help them dry.

## Riding Precautions

### Parking

Motorcycle Safety

- Park on a firm, level paved surface.
- If you must park on a slight incline or loose surface, park so that the motorcycle cannot move or fall over.
- Make sure that high-temperature parts cannot come into contact with flammable materials.
- Do not touch the engine, muffler, brakes and other high-temperature parts until they cool down.
- To reduce the likelihood of theft, always lock the handlebar and remove the key when leaving the motorcycle unattended. Use of an anti-theft device is also recommended.

### Parking with the Side Stand

1. Stop the engine.
2. Push the side stand down.
3. Slowly lean the motorcycle to the left until its weight rests on the side stand.

4. Turn the handlebar fully to the left.
  - ▶ Turning the handlebar to the right reduces stability and may cause the motorcycle to fall.
5. Turn the ignition switch to the LOCK position and remove the key. ➤ P. 40

## Riding Precautions

### Refuelling and Fuel Guidelines

Follow these guidelines to protect the engine and catalytic converter:

- Use only unleaded petrol.
- Use recommended octane number. Using lower octane petrol will result in decreased engine performance.
- Do not use fuels containing a high concentration of alcohol.  P. 121
- Do not use stale or contaminated petrol or an oil/petrol mixture.
- Avoid getting dirt or water in the fuel tank.

### Honda selectable torque control (Torque Control)

When the system detects rear wheel spin during acceleration, the system will limit the amount of torque applied to the rear wheel based on the Torque Control level selected.

Torque Control will allow some wheel spin during acceleration at the lower Torque Control levels settings. Select a level that is appropriate for your skill and riding conditions.

Torque Control does not work during deceleration and will not prevent the rear wheel from skidding due to engine braking. Do not close the throttle suddenly, especially when riding on slippery surfaces.

Torque Control may not compensate for rough road conditions or rapid throttle operation. Always consider road and weather conditions, as well as your skills and condition, when applying throttle.

If your motorcycle gets stuck in mud, snow or sand, it may be easier to free it with the Torque Control temporarily switched off.

Temporarily turning off Torque Control also may help you maintain control and balance when riding on off-road terrain.

Always use the recommended tyres and sprockets to ensure correct Torque Control operation.

## Accessories & Modifications

# Accessories & Modifications

Motorcycle Safety

We strongly advise that you do not add any accessories that were not specifically designed for your motorcycle by Honda or make modifications to your motorcycle from its original design. Doing so can make it unsafe. Modifying your motorcycle may also void your warranty and make your motorcycle illegal to operate on public roads and highways. Before deciding to install accessories on your motorcycle be certain the modification is safe and legal.

## **WARNING**

Improper accessories or modifications can cause a crash in which you can be seriously hurt or killed.

Follow all instructions in this owner's manual regarding accessories and modifications.

Do not pull a trailer with, or attach a sidecar to, your motorcycle. Your motorcycle was not designed for these attachments, and their use can seriously impair your motorcycle's handling.

## Loading

### Loading

- Carrying extra weight affects your motorcycle's handling, braking and stability. Always ride at a safe speed for the load you are carrying.
- Avoid carrying an excessive load and keep within specified load limits.
  - **Maximum weight capacity / Maximum luggage weight** P. 130
- Tie all luggage securely, evenly balanced and close to the centre of the motorcycle.
- Do not place objects near the lights or the muffler.

### **WARNING**


Overloading or improper loading can cause a crash and you can be seriously hurt or killed.


Follow all load limits and other loading guidelines in this manual.

Motorcycle Safety

# Parts Location


Operation Guide





# Instruments

Operation Guide



## Tachometer

### NOTICE

Do not operate the engine in the tachometer red zone. Excessive engine speed can adversely affect engine life.

## Tachometer red zone


(excessive engine rpm range)

**SEL** button

**SET** button

## Display Check

When the ignition switch is turned on, all the mode and digital segments will show. If any part of these displays does not come on when it should, have your dealer check for problems.



### Fuel gauge

Remaining fuel when only 1st (E) segment starts flashing:  
approximately 3.5 litres  
(0.92 US gal, 0.77 Imp gal)



If the fuel gauge indicators repeat flashing or turned off: ➡ P.103

### Handle grip heater status icon


The handle grip heater status icon will appear while the handle grip heater is on.

Clock (12-hour display)/Trip time/  
Handle grip heater level ➡ P.29

Odometer [TOTAL] & Tripmeter [TRIP A/B]  
& Mileage countdown ➡ P.23

## Instruments (Continued)

Operation Guide



**Torque Control level** → P.43

**Coolant temperature gauge ( 上 )**

- Above 122 °C:
  - High coolant temperature indicator lights
  - 6th (H) segment flashes
- ▶ Even if the engine coolant temperature is low, the cooling fan may start running when you rev up the engine. This is normal.

**Gear position indicator** → P.24

**Fuel mileage meter/Average speed** → P.25

**Air temperature gauge (AIR)**

Display range: -10 to 50 °C


- Below -11 °C: "--" displays
- Above 50 °C: "50" ( °C) flashes
- ▶ The temperature readout may be incorrect at low speeds due to reflected heat.

## Odometer [TOTAL] & Tripmeter [TRIP A/B] & Mileage countdown



### Odometer [TOTAL] & Tripmeter [TRIP A/B] & Mileage countdown

**[SEL]** button switches between the odometer, the tripmeter A, the tripmeter B and the mileage countdown.



### Odometer

Total distance ridden. When "-----" is displayed, go to your dealer for service.

### Tripmeter

Distance ridden since tripmeter was reset. When "----.-" is displayed, go to your dealer for service.

**To reset the tripmeter:** **P.28**

### Mileage countdown

Distance travelled is subtracted from a preset figure.

Display range: 999.9 to 0.0 km or mile  
When the countdown value reaches "0.0" km or mile while riding, the number will flash.

## Instruments *(Continued)*

If an indication other than the mileage countdown is displayed, the indication automatically switches to the mileage countdown and flashes "0.0" km or mile.

- ▶ To reset the mileage countdown distance, press and hold **[SEL]** button when mileage countdown is displayed.
- ▶ When changing the unit to "km" after setting the trip distance to "625 mile" or more with the unit set to "mile" unit, the thousands place digit is not displayed because the distance exceeds the maximum display range.

**To set the mileage countdown:** ➡ P. 34

## Gear position indicator

Shows 1st to 6th gear position.

When the ignition switch is turned on with the transmission in 3rd gear or higher, the gear position indicator will be displayed as shown in the illustration.



After the transmission is shifted to 2nd gear, the gear position indication will display the correct gear position.


Always use the recommended tyres and sprockets to ensure correct gear position indication.

## Fuel mileage meter & Average speed



## Fuel mileage meter & Average speed

**SET** button switches between the current fuel mileage, the average fuel mileage and the average speed.



## Current fuel mileage

Displays the current or instant fuel mileage.  
 Display range: 0.1 to 99.9 km/L (L/100km, mile/L or mile/gal)

- When your speed is less than 7 km/h (5 mph): "--.-" is displayed
- Less than 0.1 km/L (L/100km, mile/L or mile/gal) or more than 99.9 km/L (L/100km, mile/L or mile/gal) : "--.-" is displayed

When "--.-" is displayed except for the above-mentioned case, go to your dealer for service.

## Instruments *(Continued)*

### Average fuel mileage

Displays the average fuel mileage since the selected tripmeter was reset.

The average fuel mileage will be calculated based on value displayed on the tripmeter (A or B) selected. Also, the average fuel mileage for tripmeter A will be displayed when the odometer or the mileage countdown is selected.

Display range: 0.1 to 99.9 km/L (L/100km, mile/L or mile/gal)

- Initial display: "--.-" is displayed
- Less than 0.1 km/L (L/100km, mile/L or mile/gal) or more than 99.9 km/L (L/100km, mile/L or mile/gal) : "--.-" is displayed
- When the tripmeter A or B is reset: "--.-" is displayed

When "--.-" is displayed except for the above-mentioned case, go to your dealer for service.

### To reset the average fuel mileage:

➡ P.28

### **Average speed**

Displays the average speed since the selected tripmeter was reset.

The average speed will be calculated based on value displayed on the tripmeter (A or B) selected. Also, the average speed for tripmeter A will be displayed when the odometer or the mileage countdown is selected.


- Initial display: “---” is displayed  
When “---” is displayed while riding, go to your dealer for service.

**To reset the average speed:**  P.28


### Instruments (Continued)

#### To reset the tripmeter, average fuel mileage and average speed


To reset tripmeter A, average fuel mileage and average speed (these are based on tripmeter A) together, press and hold **SEL** button while tripmeter A is displayed.



To reset tripmeter B, average fuel mileage and average speed (these are based on tripmeter B) together, press and hold **SEL** button while tripmeter B is displayed.




## Clock (12-hour display) & Trip time & Handle grip heater level



### Clock (12-hour display) & Trip time & Handle grip heater level

You can switch the modes between clock and trip time mode by pressing and holding

**SET** button.



→ Press and hold **SET** button.

⇨ The heater level is displayed for about 5 seconds when the handle grip heater is on or its level is changed.

## Clock

To set the clock: ➡ P.31

## Trip time

Displays the time elapsed since the engine was started.

Display range: 0:00 to 19:59 (hours:minutes)

The display returns to 0:00 when the time elapsed exceeds 19:59.

## Handle grip heater level

When you operate the handle grip heater, the clock or trip time automatically switch to the indication for the heater level. The display will return to the ordinary mode after about 5 seconds.

To operate the handle grip heater:


➡ P.42

## Instruments *(Continued)*

### Display Setting

Following items to change sequentially.

- Clock setting
- Backlight brightness adjustment
- HISS indicator setting
- Changing the speed and mileage unit
- Changing the fuel mileage meter unit
- Setting the mileage countdown



➡ Press and hold **SEL** button and **SET** button

↳ Press **SET** button

If the ignition switch is turned off, the button is not pressed for about 30 seconds, or the handle grip heater level is changed, the control is automatically switched from the setting mode to the ordinary display. If the button is not pressed for about 30 seconds or the handle grip heater level is changed, items in the process of being set will be discarded and only items where settings have been finalised will be applied. Only if the ignition switch is turned off will items in the process of being set and those that are finalised be applied.

### 1 Clock setting:

- 1 Turn the ignition switch ON.
- 2 Press and hold **SEL** button and **SET** button, the hour digits start flashing.
- 3 Press **SEL** button until the desired hour is displayed.  
▶ Press and hold **SEL** button to advance the hour fast.



- 4 Press **SET** button. The minute digits start flashing.



**Instruments** (Continued)

- 5 Press **SEL** button until the desired minute is displayed.

▶ Press and hold **SEL** button to advance the minute fast.




- 6 Press **SET** button. The clock is set, and then the display moves to the backlight brightness adjustment.

**2 Backlight brightness adjustment:**

You can adjust the brightness to one of five levels.

- 1 Press **SEL** button. The brightness is switched.



- 2 Press **SET** button. The backlight is set, and then the display moves to the on/off of blinks of HISS indicator (HISS indicator comes on).

### 3 HISS indicator setting:

You can select the blink or off the HISS indicator.


- 1 Press **[SEL]** button to select "On" (blinks) or "OFF" (off).



- 2 Press **[SET]** button. The HISS indicator setting is set, and then the display moves to the changing of the speed and mileage unit.

### 4 Changing the speed and mileage unit:

- 1 Press **[SEL]** button to select either "km/h" & "km" or "mph" & "mile".



- 2 Press **[SET]** button. The speed and mileage unit is set, and then the display moves to the changing of the fuel mileage meter unit.

**Instruments** (Continued)**5 Changing the fuel mileage meter unit:**

- ① Press **SEL** button to select "L/100km" or "km/L".



If the "mph" for speed and "mile" for mileage are selected, the fuel mileage shown by "mile/L" or "mile/gal".



- ② Press **SET** button. The fuel mileage meter unit is set, and then the display moves to the setting of mileage countdown.

**6 Setting the mileage countdown:**

- ① The preset figure is displayed and the third digit will be flashing.



- ② To set the third digit, press **SEL** button until the desired figure appears.  
▶ Press and hold **SEL** button to advance the figure fast.

- ③ Press **SET** button. The second digit starts flashing.



- ④ Repeat the steps ② and ③ for the second and first digits.

- 5 Press **SET** button. The trip distance is set, and then the display will return to the ordinary display.

The trip distance will not be reset when you complete setting of the mileage countdown by pressing **SET** button only or when you set the trip distance to the same as the current distance.

When entering the setting mode using “km” unit after setting the trip distance to “625 mile” or more with the unit set to “mile”, “---.” will appear because the distance exceeds the maximum display range.

Press **SEL** button to display “000.0”, and then set the trip distance again if necessary. Pressing **SET** button while “---.” is displayed will return the display to the ordinary display and keep the previous trip distance.

# Indicators

Operation Guide

← Left turn signal indicator

 **Low oil pressure indicator**

Comes on when the ignition switch is turned on.  
Goes off when the engine starts.

**If it comes on while engine is running:** → P.100

N **Neutral indicator**

Comes on when the transmission is in Neutral.

 **High beam indicator**

 **PGM-FI (Programmed Fuel Injection) malfunction indicator lamp (MIL)**

Comes on briefly when the ignition switch is turned on with the engine stop switch in the ○ (Run) position.

Comes on when the ignition switch is turned on with the engine stop switch in the ⊗ (Off) position.

**If it comes on while engine is running:**

→ P.100

 **Low fuel indicator**


- Comes on briefly when the ignition switch is turned on.
- Comes on when there is only reserve fuel left in the fuel tank.  
Remaining fuel when low fuel indicator comes on:  
3.5 litres (0.92 US gal, 0.77 Imp gal)



**Torque Control indicator**

- Comes on when the ignition switch is turned on. Goes off when your speed reaches approximately 10 km/h (6 mph) to indicate Torque Control is ready to work.
- Blinks when Torque Control is operating.

**If it comes on while riding:** ➔ P.102



**ABS (Anti-lock Brake System) indicator**

Comes on when the ignition switch is turned on. Goes off when your speed reaches approximately 10 km/h (6 mph).

**If it comes on while riding:** ➔ P.101

**HISS indicator** ➔ P.118

- Comes on briefly when the ignition switch is turned on with the engine stop switch in the (Run) position. Goes off if the ignition key has the correct coding.
- Flashes every 2 seconds for 24 hours when the ignition switch is turned off.

**Torque Control OFF indicator**

Comes on when the Torque Control is turned off.

**Right turn signal indicator**

**High coolant temperature indicator**

Comes on briefly when the ignition switch is turned on.

**If it comes on while riding:** ➔ P.99

# Switches

Operation Guide

 **Torque Control switch**  
Torque Control level setting and  
Torque Control on/off. 

 **PASS Passing light control switch**  
Flashes the high beam headlight.

**Headlight dimmer switch**

- : High beam
- : Low beam

 **Handle grip heater switch**  


 **Turn signal switch**

- The turn signal will automatically stop when you complete the turn.
- When used for a lane change, the turn signal is automatically stopped in 7 seconds or after riding 120 m (131 yards).
  - ▶ You can manually cancel the turn signal by pressing the switch in.
  - ▶ In some cases, the timing at which the turn signal stops is changed.
  - ▶ Always use the recommended tyres to ensure correct automatic cancellation operation.

### Ignition Switch

Switches the electrical system on/off, locks the steering.

▶ Key can be removed when in the OFF or LOCK position.

### Engine stop switch

Should normally remain in the  (Run) position.

▶ In an emergency, switch to the  (Off) position to stop the engine.



### Hazard switch

Switchable when the ignition switch is on. Can be turned to off regardless of the ignition switch position.

▶ The signals continue flashing with the ignition switch in OFF or LOCK after the hazard switch is on.



### Start button





### Horn button

## Switches *(Continued)*

### Steering Lock

Lock the steering when parking to help prevent theft.

A U-shaped wheel lock or similar device is also recommended.



### Locking




- 1 Turn the handlebars all the way to the left or right.
- 2 Push the key down, and turn the ignition switch to the LOCK position.
  - ▶ Jiggle the handlebars if the lock is difficult to engage.
- 3 Remove the key.

### Unlocking

Insert the key, push it in, and turn the ignition switch to the OFF position.

# Handle Grip Heater

VFR800X is equipped with a handle grip heater that warms up your hands during ride. Wear gloves to protect your hands from the heated grips.



## Handle grip heater indicator:

Displayed when the handle grip heater is on. The selected heater level is indicated by the number of times the indicator blinks when the heater is turned on and the heater level is changed. For example, If you select heater level 5, the indicator blinks 5 times and repeats it 7 times.

## Heater level:

The selected heater level is indicated for a few seconds when the handle grip heater switch is operated.

## Handle grip heater status icon:

Displayed when the handle grip heater is on.

**If the "E1", "E2" or "E3" blinks:** P.103



## Handle Grip Heater *(Continued)*

### To operate the handle grip heater


- 1 Start the engine. ▣ P. 45
- 2 Press the handle grip heater switch. The handle grip heater is on.
  - ▶ The status icon will be appeared on the display when the handle grip heater operates.
- 3 Select the heater level by pressing the switch.
  - ▶ The clock or trip time on the display automatically switch to the indication of the heater level. The indication will return to the ordinary mode after blinking for about 5 seconds.
  - ▶ Do not leave the handle grip heater in the high position for a long time on a warm day.
- 4 To turn off the heater, press the switch until the status icon on the display is disappeared. Also to turn off, press and hold the switch.

Do not use the handle grip heater with the engine at idle for a long time. It may result in

a low (or dead) battery.

Maintains the selected level when the ignition switch is turned off.

- ▶ The heater level is not changed if the ignition switch is turned to the OFF position within 5 seconds after heater level change.



→ Press the handle grip heater switch.

⇨ Press and hold the handle grip heater switch.

# Honda selectable torque control (Torque Control)

Torque Control level (engine power control) can be selected or turned on/off.

- ▶ Do not operate the Torque Control switch while riding. Stop the motorcycle first and the turn off or on and select the desired level.
- ▶ The Torque Control setting cannot be changed or turned off when the system is activated (Torque Control indicator flashing).
- ▶ Each time the ignition switch is turned to the ON position, the Torque Control level will automatically be set to level 2 (max).
- ▶ When the Torque Control is turned from the off position to the on position, it will automatically be set to level 2 (max).


## Torque Control level setting

The level can be selected by pressing the Torque Control switch.

- ▶ Level 2 is the maximum Torque Control level
- ▶ Level 1 is the minimum Torque Control level

## Torque Control on and off


Torque Control can be turned on and off by press and hold the Torque Control switch.



Torque Control switch

## Honda selectable torque control (Torque Control) (Continued)


Operation Guide



- ➔ Press the Torque Control switch
- ⇨ Press and hold the Torque Control switch

# Starting the Engine

Start your engine using the following procedure, regardless of whether the engine is cold or warm.



## NOTICE

- If the engine does not start within 5 seconds, turn the ignition off and wait 10 seconds before trying to start the engine again to recover battery voltage.
- Extended fast idling and revving the engine can damage the engine, and the exhaust system.
- Snapping the throttle or fast idling for more than about 5 minutes may cause exhaust pipe discoloration.
- The engine will not start if the throttle is fully open.

- 1 Make sure the engine stop switch is in the  (Run) position.
- 2 Turn the ignition switch to the ON position.
- 3 Shift the transmission to Neutral (**N** indicator comes on). Alternatively, pull in the clutch lever to start your motorcycle with the transmission in gear so long as the side stand is raised.
- 4 Press the start button with the throttle completely closed.

If the engine does not start:


- 1 Open the throttle fully and press the start button for 5 seconds.
- 2 Repeat the normal starting procedure.
- 3 If the engine starts, open the throttle slightly if idling is unstable.
- 4 If the engine does not start, wait 10 seconds before trying steps 1 & 2 again.

**If Engine Will Not Start**  P.98

## Shifting Gears


Your motorcycle transmission has six forward gears in a one-down, five-up shift pattern.

Operation Guide



If you put the motorcycle in gear with the side stand down, the engine will shut off.

# Refuelling



Do not fill with fuel above the level plate.

**Fuel type:** Unleaded petrol only

**Fuel octane number:** Your motorcycle is designed to use Research Octane Number (RON) 91 or higher.

**Tank capacity:** 20.8 litres (5.50 US gal, 4.58 Imp gal)

**Refuelling and Fuel Guidelines** ➔ P.15

## Opening the Fuel Fill Cap

Open the lock cover, insert the ignition key, and turn it clockwise to open the fuel fill cap.

## Closing the Fuel Fill Cap

- 1 After refuelling, push the fuel fill cap closed until it locks.
- 2 Remove the key and close the lock cover.
  - ▶ The key cannot be removed if the fuel fill cap is not locked.

## **⚠ WARNING**

Petrol is highly flammable and explosive. You can be burned or seriously injured when handling fuel.

- Stop the engine, and keep heat, sparks, and flame away.
- Handle fuel only outdoors.
- Wipe up spills immediately.


# Storage Equipment

## Helmet Holder

The helmet holder is located under the rear seat. The helmet set wire is stored in the tool kit.  P. 67

▶ Use the helmet holder only when parked.

■ Removing the Rear Seat  P.68




## WARNING

Riding with a helmet attached to the holder can interfere with the rear wheel or suspension and could cause a crash in which you can be seriously hurt or killed.

Use the helmet holder only while parked. Do not ride with a helmet secured by the holder.

### Tool Kit/Document Bag

The tool kit is located under the rear seat. Secure the tool kit with the rubber strap A (large-diameter) as shown in the illustration. The document bag is located under the front seat.




Removing the Rear Seat ➡ P.68

### U-shaped Lock

A U-shaped lock is held in place above the rear fender.

- 1 Remove the rubber strap A (large-diameter) and tool kit from the rear fender.
- 2 Place the U-shaped lock onto the rear fender, and then secure it by hooking the rubber strap B (small-diameter) at the three points as shown in the illustration.
  - ▶ Some U-shaped locks may not fit in the compartment due to their size or design.




continued 49

## Storage Equipment *(Continued)*

- 3 Place the tool kit onto the U-shaped lock, then secure the tool kit and the U-shaped lock by hooking the rubber strap A at the two points as shown in the illustration.

### Tool kit



Rubber strap A

Hook points

Removing the Rear Seat  P.68

# Maintenance

Please read “Importance of Maintenance” and “Maintenance Fundamentals” carefully before attempting any maintenance. Refer to “Specifications” for service data.

<b>Importance of Maintenance</b> .....	P. 52	<b>Brakes/Clutch</b> .....	P. 81
<b>Maintenance Schedule</b> .....	P. 53	<b>Side Stand</b> .....	P. 84
<b>Maintenance Fundamentals</b> .....	P. 56	<b>Drive Chain</b> .....	P. 85
<b>Tool kit</b> .....	P. 67	<b>Throttle</b> .....	P. 88
<b>Removing &amp; Installing Body Components</b> ...	P. 68	<b>Other Adjustments</b> .....	P. 89
Rear Seat .....	P. 68	Clutch and Brake Levers .....	P. 89
Front Seat .....	P. 69	Front Suspension .....	P. 90
Right Under Cover .....	P. 71	Rear Suspension .....	P. 92
Battery Cover .....	P. 72	Headlight Aim .....	P. 93
Battery .....	P. 74	Front Seat Height .....	P. 94
<b>Engine Oil</b> .....	P. 75		
<b>Coolant</b> .....	P. 79		

## Importance of Maintenance

### Importance of Maintenance

Keeping your motorcycle well-maintained is absolutely essential to your safety and to protect your investment, obtain maximum performance, avoid breakdowns, and reduce air pollution. Maintenance is the owner's responsibility. Be sure to inspect your motorcycle before each ride, and perform the periodic checks specified in the Maintenance Schedule. ■ P. 53

Maintenance

### **▲ WARNING**

Improperly maintaining your motorcycle or failing to correct a problem before you ride can cause a crash in which you can be seriously hurt or killed.

Always follow the inspection and maintenance recommendations and schedules in this owner's manual.

### Maintenance Safety

Always read the maintenance instructions before you begin each task, and make sure that you have the tools, parts, and skills required. We cannot warn you of every conceivable hazard that can arise in performing maintenance. Only you can decide whether or not you should perform a given task.

Follow these guidelines when performing maintenance.

- Stop the engine and remove the key.
- Park your motorcycle on a firm, level surface using the side stand or a maintenance stand to provide support.
- Allow the engine, muffler, brakes, and other high-temperature parts to cool before servicing as you can get burned.
- Run the engine only when instructed, and do so in a well-ventilated area.

## Maintenance Schedule

The maintenance schedule specifies the maintenance requirements necessary to ensure safe, dependable performance, and proper emission control.

Maintenance work should be performed in accordance with Honda's standards and specifications by properly trained and equipped technicians. Your dealer meets all of these requirements. Keep an accurate record of maintenance to help ensure that your motorcycle is properly maintained. Make sure that whomever performs the maintenance completes this record.

All scheduled maintenance is considered a normal owner operating cost and will be charged for by your dealer. Retain all receipts. If you sell the motorcycle, these receipts should be transferred with the motorcycle to the new owner.

Honda recommends that your dealer should road test your motorcycle after each periodic maintenance is carried out.

Maintenance

*continued* 53

## Maintenance Schedule

Items	Pre-ride Check P. 56	Frequency *1						Annual Check	Regular Replace	Refer to page
		× 1,000 km	1	12	24	36	48			
		× 1,000 mi	0.6	8	16	24	32			
Fuel Line				I	I	I	I	I		-
Fuel Level		I								-
Throttle Operation		I		I	I	I	I	I		88
Air Cleaner *2						R		R		-
Spark Plug						I		R		-
Valve Clearance						I		I		-
Engine Oil		I	R	R	R	R	R	R	R	75
Engine Oil Filter			R	R	R	R	R	R	R	77
Engine Idle Speed			I	I	I	I	I	I		-
Radiator Coolant *3		I		I	I	I	I	I	3 Years	79
Cooling System				I	I	I	I	I		-
Secondary Air Supply System						I		I		-

Maintenance

### Maintenance Level

-  : Intermediate. We recommend service by your dealer, unless you have the necessary tools and are mechanically skilled. Procedures are provided in an official Honda Shop Manual.
-  : Technical. In the interest of safety, have your motorcycle serviced by your dealer.

### Maintenance Legend

- I** : Inspect (clean, adjust, lubricate, or replace, if necessary)
- L** : Lubricate
- R** : Replace

## Maintenance Schedule

Items	Pre-ride Check P. 56	Frequency *1						Annual Check	Regular Replace	Refer to page	
		× 1,000 km	1	12	24	36	48				
		× 1,000 mi	0.6	8	16	24	32				
Drive Chain	I		Every 1,000 km (600 mi): I L								85
Drive Chain Slider				I	I	I	I			87	
Brake Fluid *3	I			I	I	I	I	I	2 Years	81	
Brake Pads Wear	I			I	I	I	I	I		82	
Brake System			I	I	I	I	I	I		56	
Brakelight Switch				I	I	I	I	I		83	
Headlight Aim				I	I	I	I	I		93	
Lights/Horn	I									-	
Engine Stop Switch	I									-	
Clutch System				I	I	I	I	I		56	
Clutch fluid *3	I			I	I	I	I	I	2 Years	83	
Side Stand	I			I	I	I	I	I		84	
Suspension				I	I	I	I	I		90	
Nuts, Bolts, Fasteners			I	I	I	I	I	I		-	
Wheels/Tyres		I		I	I	I	I	I		64	
Steering Head Bearings			I	I	I	I	I	I		-	

**Notes:**

\*1 : At higher odometer readings, repeat at the frequency interval established here.

\*2 : Service more frequently when riding in unusually wet or dusty areas.

\*3 : Replacement requires mechanical skill.

## Maintenance Fundamentals

### Pre-ride Inspection

To ensure safety, it is your responsibility to perform a pre-ride inspection and make sure that any problem you find is corrected. A pre-ride inspection is a must, not only for safety, but because having a breakdown, or even a flat tyre, can be a major inconvenience.


Check the following items before you ride motorcycle:

- Fuel level-Fill fuel tank when necessary.  P. 47
- Throttle-Check for smooth opening and full closing in all steering positions.  P. 88
- Engine oil level-Add engine oil if necessary. Check for leaks.  P. 75
- Coolant level-Add coolant if required. Check for leaks.  P. 79
- Drive chain-Check condition and slack, adjust and lubricate if necessary.  P. 61, 85
- Brakes-Check operation; Front and Rear: check brake fluid level and pads wear.  P. 81
- Lights and horn-Check that lights, indicators and horn function properly.
- Engine stop switch-Check for proper function.  P. 39
- Clutch-Check clutch fluid level.  P. 83
- Side stand ignition cut-off system-Check for proper function.  P. 84
- Wheels and tyres-Check condition, air pressure and adjust if necessary.  P. 64

## Maintenance Fundamentals

### Replacing Parts

Always use Honda Genuine Parts or their equivalents to ensure reliability and safety. When ordering coloured components, specify the model name, colour, and code mentioned on the colour label. The colour label is attached to the rear fender under the rear seat. ➤ P. 68



### **⚠ WARNING**

Installing non-Honda parts may make your motorcycle unsafe and cause a crash in which you can be seriously hurt or killed.

Always use Honda Genuine Parts or equivalents that have been designed and approved for your motorcycle.

## Maintenance Fundamentals

### Battery

Your motorcycle has a maintenance-free type battery. You do not have to check the battery electrolyte level or add distilled water. Clean the battery terminals if they become dirty or corroded.

Do not remove the battery cap seals. There is no need to remove the cap when charging.

#### NOTICE

Your battery is a maintenance-free type and can be permanently damaged if the cap strip is removed.



This symbol on the battery means that this product must not be treated as household waste.

#### NOTICE

An improperly disposed of battery can be harmful to the environment and human health.

Always confirm local regulations for battery disposal.

### WARNING

The battery gives off explosive hydrogen gas during normal operation.

A spark or flame can cause the battery to explode with enough force to kill or seriously hurt you.


Wear protective clothing and a face shield, or have a skilled mechanic do the battery servicing.

#### Cleaning the Battery Terminals

1. Remove the battery.  P. 74
2. If the terminals are starting to corrode and are coated with a white substance, wash with warm water and wipe clean.

## Maintenance Fundamentals

3. If the terminals are heavily corroded, clean and polish the terminals with a wire brush or sandpaper. Wear safety glasses.



4. After cleaning, reinstall the battery.

The battery has a limited life span. Consult your dealer about when you should replace the battery. Always replace the battery with another maintenance-free battery of the same type.

### NOTICE


Installing non-Honda electrical accessories can overload the electrical system, discharging the battery and possibly damaging the system.

## Fuses

Fuses protect the electrical circuits on your motorcycle. If something electrical on your motorcycle stops working, check for and replace any blown fuses. ➤ P. 114

### Inspecting and Replacing Fuses

Turn off the ignition switch to remove and inspect fuses. If a fuse is blown, replace with a fuse of the same rating. For fuse ratings, see "Specifications." ➤ P. 132



### NOTICE

Replacing a fuse with one that has a higher rating greatly increases the chance of damage to the electrical system.

## Maintenance Fundamentals

If a fuse fails repeatedly, you likely have an electrical fault. Have your motorcycle inspected by your dealer.

### Engine Oil

Engine oil consumption varies and oil quality deteriorates according to riding conditions and time elapsed.

Check the engine oil level regularly, and add the recommended engine oil if necessary. Dirty oil or old oil should be changed as soon as possible.


#### Selecting the Engine Oil

For recommended engine oil, see “Specifications”. ➤ P. 131


If you use non-Honda engine oil, check the label to make sure that the oil satisfies all of the following standards:

- JASO T 903 standard\*1: MA
- SAE standard\*2: 10W-30
- API classification\*3: SG or higher

- \*1. The JASO T 903 standard is an index for engine oils for 4-stroke motorcycle engines. There are two classes: MA and MB. For example, the following label shows the MA classification.



- \*2. The SAE standard grades oils by their viscosity.  
 \*3. The API classification specifies the quality and performance rating of engine oils. Use SG or higher oils, excluding oils marked as “Energy Conserving” or “Resource Conserving” on the circular API service symbol.



## Maintenance Fundamentals

### Brake Fluid (Clutch Fluid)

Do not add or replace brake fluid, except in an emergency. Use only fresh brake fluid from a sealed container. If you do add fluid, have the brake and clutch system serviced by your dealer as soon as possible.

#### NOTICE

Brake fluid can damage plastic and painted surfaces. Wipe up spills immediately and wash thoroughly.

#### Recommended brake fluid:


Honda DOT 4 Brake Fluid or equivalent

### Drive Chain

The drive chain must be inspected and lubricated regularly. Inspect the chain more frequently if you often ride on bad roads, ride at high speed, or ride with repeated fast acceleration.

If the chain does not move smoothly, makes strange noises, has damaged rollers or loose pins or missing O-rings, or kinks, have the chain inspected by your dealer.

Also inspect the engine sprocket and rear wheel sprocket. If either has worn or damaged teeth, have the sprocket replaced by your dealer.



#### NOTICE

Use of a new chain with worn sprockets will cause rapid chain wear.


## Maintenance Fundamentals

### Cleaning and Lubricating

After inspecting the slack, clean the chain and sprockets while rotating the rear wheel. Use a dry cloth with chain cleaner designed specifically for O-ring chains, or neutral detergent. Use a soft brush if the chain is dirty. After cleaning, wipe dry and lubricate with the recommended lubricant. If not available, use SAE 80 or 90 gear oil.

#### Recommended lubricant:

Drive chain lubricant designed specifically for O-ring chains.  
If not available, use SAE 80 or 90 gear oil.



Do not use a steam cleaner, a high pressure cleaner, a wire brush, volatile solvent such as petrol and benzene, abrasive cleaner, chain cleaner or lubricant NOT designed specifically for O-ring chains as these can damage the rubber O-ring seals.  
Avoid getting lubricant on the brakes or tyres.  
Avoid applying excess chain lubricant to prevent spray onto your clothes and the motorcycle.

#### Recommended Coolant

Pro Honda HP coolant is a pre-mixed solution of antifreeze and distilled water.

#### Concentration:

50 % antifreeze and 50 % distilled water

## Maintenance Fundamentals

A concentration of antifreeze below 40 % will not provide proper corrosion and cold temperature protection. A concentration of up to 60 % will provide better protection in colder climates.

### NOTICE

Using coolant not specified for aluminium engines or using ordinary tap water can cause corrosion.


### Air Cleaner

This motorcycle is equipped with a viscous type air cleaner element.

Air blow cleaning or any other cleaning can degrade the viscous element performance and cause the intake of dust.

Do not perform the maintenance.

Should be serviced by your dealer.



## Maintenance Fundamentals


### Tyres (Inspecting/Replacing)

#### Checking the Air Pressure

Visually inspect your tyres and use an air pressure gauge to measure the air pressure at least once a month or any time you think the tyres look low. Always check air pressure when your tyres are cold.


#### Inspecting for Damage

Inspect the tyres for cuts, slits, or cracks that exposes fabric or cords, or nails or other foreign objects embedded in the side of the tyre or the tread. Also inspect for the bumps or bulges in the side walls of the tyres.




#### Inspecting for Abnormal Wear

Inspect the tyres for signs of abnormal wear on the contact surface.



### Inspecting Tread Depth

Inspect the tread wear indicators. If they become visible, replace the tyres immediately. For safe riding, you should replace the tyres when the minimum tread depth is reached.



### **⚠ WARNING**

Riding on tyres that are excessively worn or improperly inflated can cause a crash in which you can be seriously hurt or killed.

Follow all instructions in this owner's manual regarding tyre inflation and maintenance.

#### Germany

German law prohibits use of tyres whose tread depth is less than 1.6 mm.

## Maintenance Fundamentals

Have your tyres replaced by your dealer.  
For recommended tyres, air pressure and minimum tread depth, see "Specifications".

▶ P. 131

Follow these guidelines whenever you replace tyres.

- Use the recommended tyres or equivalents of the same size, construction, speed rating, and load range.
- Have the wheel balanced with Honda Genuine balance weights or equivalents after the tyre is installed.
- Do not install a tube inside a tubeless tyre on this motorcycle. Excessive heat build-up can cause the tube to burst.
- Use only tubeless tyres on this motorcycle. The rims are designed for tubeless tyres, and during hard acceleration or braking, a tube-type tyre could slip on the rim and cause the tyre to rapidly deflate.

## WARNING

Installing improper tyres on your motorcycle can adversely affect handling and stability, and can cause a crash in which you can be seriously hurt or killed.

Always use the size and type of tyres recommended in this owner's manual.

## Tool kit

The tool kit is stored under the raer seat.


➤ P. 68

You can perform some roadside repairs, minor adjustments and parts replacement with the tools contained in the kit.

- Standard/Phillips screwdriver
- Screwdriver handle
- 14 × 17 mm Open end wrench
- Helmet set wire
- 5 mm Hex wrench
- Pin spanner
- Fuse puller
- Extension bar
- Front suspension spring preload adjustment spanner

## Removing & Installing Body Components

### Rear Seat



Maintenance

### Removal

1. Insert the ignition key into the seat lock.
2. Turn it clockwise, then pull the rear seat up and back.


### Installation

1. Insert the prongs into the rear stays on the frame.
  2. Push down on the rear of the rear seat.  
Make sure that the seat is locked securely in position to pull it up lightly.
- The seat locks automatically when closed.  
Take care not to lock your key in the compartment under the rear seat.

## Removing & Installing Body Components ▶ Front Seat

### Front Seat

#### Removal




1. Remove the rear seat. ▶ P. 68
2. Remove the mounting bolts and collars, and then pull the front seat back and up.

#### Installation

1. **When setting the high seat position:**  
Install the front seat by aligning its recesses with the front side stays and placing its prong on the front centre stay.

##### High position:



Maintenance


continued 69

## Removing & Installing Body Components ▶ Front Seat


### When setting the low seat position:

Install the front seat by aligning its recesses with the front side stays and its prong with the front centre stay.

#### Low position:



2. Install the collars and mounting bolts.
3. Tighten the mounting bolts securely.
4. Make sure that the mount positions of the front seat prong and the adjust plates are the same seat position. ▶ P. 96




### 5. Install the rear seat.

Make sure that the seat is locked securely in position to pull it up lightly.

For the front seat height adjustment, see "Changing the Front Seat Height." ▶ P. 94

Removing & Installing Body Components ► Right Under Cover

## Right Under Cover



The right under cover must be removed to replace the engine oil filter.

### Removal

1. Remove the bolts and collars.
2. Remove the right under cover.

### Installation

Install the parts in the reverse order of removal.

## Removing & Installing Body Components ▶ Battery Cover


### Battery Cover

The battery cover must be removed to remove the battery, to service the main and fuse box fuses.

#### Removal

When setting the high seat position:


1. Remove the front seat. ▶ P. 69
2. Remove the clips.
3. Remove the battery cover.




## Removing & Installing Body Components ▶ Battery Cover

When setting the low seat position:

1. Remove the front seat. ▶ P. 69
2. Remove the clips.
3. Move the right rib of the battery cover to the inside of the right adjust plate (1).



4. While pressing down the rear left part of the battery cover (2), pull up the right part of it and remove the battery cover to the right side (3).




### Installation

Install the parts in the reverse order of removal.

## Removing & Installing Body Components ► Battery

### Battery



#### Removal

Make sure the ignition switch is off.

1. Remove the battery cover. ► P. 72
2. Unhook the rubber strap.

3. Disconnect the negative ⊖ terminal from the battery.
4. Disconnect the positive ⊕ terminal from the battery.
5. Remove the battery taking care not to drop the terminal nuts.

#### Installation

Install the parts in the reverse order of removal. Always connect the positive ⊕ terminal first. Make sure that bolts and nuts are tight.


Readjust the clock after the battery is reconnected since the clock goes wrong once the battery disconnected.

For proper handling of the battery, see "Maintenance Fundamentals." ► P. 56  
"Battery Goes Dead." ► P. 111

## Engine Oil

### Checking the Engine Oil

1. If the engine is cold, idle the engine for 3 to 5 minutes.
2. Turn the ignition switch off, and wait for 2 to 3 minutes.
3. Place your motorcycle in an upright position on a firm, level surface.
4. Check that the oil level is between the upper and lower level marks in the oil level inspection window.



## Engine Oil ▶ Adding Engine Oil

### Adding Engine Oil

If the engine oil is below or near the lower level mark, add the recommended engine oil.

▶ P. 60, 131

1. Remove the oil fill cap. Add the recommended oil until it reaches the upper level mark.
  - ▶ Place your motorcycle in an upright position on a firm, level surface when checking the oil level.
  - ▶ Do not overfill above the upper level mark.
  - ▶ Make sure no foreign objects enter the oil filler opening.
  - ▶ Wipe up any spills immediately.

2. Securely reinstall the oil fill cap.

#### NOTICE

Overfilling with oil or operating with insufficient oil can cause damage to your engine. Do not mix different brands and grades of oil. They may affect lubrication and clutch operation.

For the recommended oil and oil selection guidelines, see "Maintenance Fundamentals". ▶ P. 56

## Changing Engine Oil & Filter

Changing the oil and filter requires special tools. We recommend that you have your motorcycle serviced by your dealer.

Use a new Honda Genuine oil filter or equivalent specified for your model.


### NOTICE

Using the wrong oil filter can result in serious damage to the engine.

1. Place your motorcycle on a firm, level surface and lower the side stand.
2. Remove the right under cover. ▣ P. 71
3. If the engine is cold, idle the engine for 3 to 5 minutes.
4. Turn the ignition switch off, and wait for 2 to 3 minutes.
5. Place a drain pan under the drain bolt.

### Engine Oil ► Changing Engine Oil & Filter


6. Remove the oil fill cap, drain bolt, and sealing washer to drain the oil.



## Engine Oil ► Changing Engine Oil & Filter

- Remove the oil filter with a filter wrench from the right side and let the remaining oil drain out.

► Discard the oil and oil filter at an approved recycling centre.



Maintenance

- Apply a thin coat of engine oil to the rubber seal of a new oil filter.
- Install the new oil filter and tighten.

**Torque:** 26 N·m (2.7 kgf·m, 19 lbf·ft).

- Install a new sealing washer onto the drain bolt. Tighten the drain bolt.

**Torque:** 30 N·m (3.1 kgf·m, 22 lbf·ft).

- Fill the crankcase with the recommended oil (►P. 60) and install the oil fill cap.

### Required oil

#### When changing oil & engine oil filter:

3.1 litres (3.3 US qt, 2.7 Imp qt)

#### When changing oil only:


2.9 litres (3.1 US qt, 2.6 Imp qt)

- Check the oil level. ►P. 75
- Check that there are no oil leaks.
- Install the right under cover.

## Coolant

### Checking the Coolant

1. Place your motorcycle on a firm, level surface.
2. Hold your motorcycle in an upright position.
3. Check that the coolant level is between the UPPER and LOWER level marks in the reserve tank.



If the coolant level is dropping noticeably or the reserve tank is empty, you likely have a serious leak. Have your motorcycle inspected by your dealer.

### Adding Coolant

If the coolant level is below the LOWER level mark, add the recommended coolant (➤ P. 62) until the level reaches the UPPER level mark. Add fluid only from the reserve tank cap and do not remove the radiator cap.

1. Remove the front seat. ➤ P. 69

## Coolant ► Changing Coolant


2. Remove the reserve tank cap and add fluid while monitoring the coolant level.
  - Do not overfill above the UPPER level mark.
  - Make sure no foreign objects enter the reserve tank opening.
3. Securely reinstall the cap.
4. Install the front seat.

Maintenance

### **⚠ WARNING**

Removing the radiator cap while the engine is hot can cause the coolant to spray out, potentially scalding you.

Always let the engine and radiator cool down before removing the radiator cap.



## Changing Coolant

Have your dealer change the coolant unless you have the proper tools and are mechanically qualified.


## Brakes/Clutch

### Checking Brake Fluid

1. Place your motorcycle in an upright position on a firm, level surface.
2. **Front** Check that the brake fluid reservoir cap is horizontal and that the fluid level is above the LOWER level mark.
3. **Rear** Check that the brake fluid reservoir is horizontal and that the level is between the LOWER level and UPPER level marks.

If the brake fluid level in either reservoir is below the LOWER level mark or the brake lever and pedal freeplay becomes excessive, inspect the brake pads for wear. If the brake pads are not worn, you most likely have a leak. Have your motorcycle inspected by your dealer.

Maintenance




Brakes/Clutch ▶ Inspecting the Brake Pads

## Inspecting the Brake Pads

Check the condition of the brake pad wear indicators.

The pads need to be replaced if a brake pad is worn to the bottom of the indicator.



1. **Front** Inspect the brake pads from in front of the brake caliper.  
▶ Always inspect both left and right calipers.
2. **Rear** Inspect the brake pads from the rear right and left of the motorcycle.


If necessary have the pads replaced by your dealer.

Always replace both left and right brake pads at the same time.


## Brakes/Clutch ▶ Adjusting the Brakelight Switch

## Adjusting the Brakelight Switch

Check the operation of the brakelight switch. Hold the brake light switch and turn the adjusting nut in the direction A if the switch operates too late, or turn the nut in the direction B if the switch operates too soon.



## Checking the Clutch Fluid




1. Place your motorcycle in an upright position on a firm, level surface.
2. Check that the clutch fluid reservoir cap is horizontal and that the fluid level is above the LOWER level mark.

If the fluid level is low or if you find fluid leaks, or deterioration or cracks in the hoses and fittings, have the clutch system serviced by your dealer.

## Side Stand

Maintenance



1. Check that the side stand operates smoothly. If the side stand is stiff or squeaky, clean the pivot area and lubricate the pivot bolt with clean grease.
2. Check the spring for damage or loss of tension.
3. Sit on the motorcycle, put the transmission in Neutral, and raise the side stand.
4. Start the engine, pull the clutch lever in, and shift the transmission into gear.
5. Lower the side stand all the way. The engine should stop as you lower the side stand. If the engine doesn't stop, have your motorcycle inspected by your dealer.

## Drive Chain

### Inspecting the Drive Chain Slack

Check the drive chain slack at several points along the chain. If the slack is not constant at all points, some links may be kinked and binding.

Have the chain inspected by your dealer.


1. Stop the engine. Place the transmission in Neutral.
2. Place your motorcycle on the side stand on a level surface.

3. Check the slack in the lower half of the drive chain midway between the sprockets.

#### Drive chain slack:

30 to 40 mm (1.2 to 1.6 in)

- Do not ride your motorcycle if the slack exceeds 50 mm (2.0 in).



4. Roll the motorcycle forward and check that the chain moves smoothly.

**Drive Chain ▶ Adjusting the Drive Chain Slack**

5. Inspect the sprockets. **▶** P. 61
6. Clean and lubricate the drive chain.  
**▶** P. 62

**Adjusting the Drive Chain Slack**

Adjusting the chain requires special tools. Have the drive chain slack adjusted by your dealer.


1. Stop the engine. Place the transmission in Neutral.
2. Place your motorcycle on the side stand on a level surface.
3. Loosen the bearing holder pinch bolt.
4. Turn the bearing holder clockwise or counterclockwise to obtain the proper chain slack with the pin spanner and extension bar.

5. Tighten the bearing holder pinch bolt to the specified torque.

**Torque:** 74 N·m (7.5 kgf·m, 55 lbf·ft).

If a torque wrench was not used for this installation, see your dealer as soon as possible to verify proper assembly. Improper assembly may lead to loss of braking capacity.

6. Check drive chain slack. **▶** P. 85




## Checking the Drive Chain Wear

Check the chain wear label when adjusting the drive chain. If the red zone on the label aligns with the tip of driven sprocket teeth after the chain has been adjusted to the proper slack, the chain is excessively worn and must be replaced.

### Chain:

DID 525HV3 or RK 525ROZ6


If necessary have the drive chain replaced by your dealer.



## Drive Chain ▶ Checking the Drive Chain Slider

### Checking the Drive Chain Slider

Check the condition of the drive chain slider. The drive chain slider needs to be replaced if it is worn to the wear limit line. If necessary have the drive chain slider replaced by your dealer.



## Throttle


### Checking the Throttle

With the engine off, check that the throttle rotates smoothly from fully closed to fully open in all steering positions and throttle freeplay is correct. If the throttle does not move smoothly, close automatically, or if the cable is damaged, have the motorcycle inspected by your dealer.

Maintenance

#### Freeplay at the throttle grip flange:

2 to 6 mm (0.1 to 0.2 in)



## Other Adjustments

### Adjusting the Clutch and Brake Levers

You can adjust the distances between the tip of the clutch lever and handle grip, and between the tip of the brake lever and handle grip.

### Adjustment method


Turn the adjuster until the numbers aligns with the index mark while pushing the lever forward in the desired position.

After adjustment, check that the levers operate correctly before riding.

#### NOTICE

Do not turn the adjuster beyond its natural limit.

Maintenance




Other Adjustments ▶ Adjusting the Front Suspension

## Adjusting the Front Suspension

### I Spring Preload

You can adjust the spring preload by the adjuster to suit the load or the road surface. Turn the adjuster using the preload spanner provided in the tool kit.  67


Turn clockwise to increase spring preload (hard), or turn counterclockwise to decrease spring preload (soft). The standard position is 5th groove from the top aligning with the top surface of the fork bolt.



## Other Adjustments ▶ Adjusting the Front Suspension

## Rebound Damping


You can adjust the rebound damping by the adjuster to suit the load or the road surface. Turn clockwise to increase rebound damping (hard), or turn counterclockwise to decrease rebound damping (soft). The standard position is 1 1/2 turns from the maximum setting so that the punch mark on the adjuster aligns with the reference mark.

**NOTICE**

Do not turn the adjuster beyond its natural limits.  
Adjust both left and right forks to the same spring preload and rebound damping.

**Other Adjustments ▶ Adjusting the Rear Suspension****Adjusting the Rear Suspension****I Spring Preload**


You can adjust the spring preload by the adjuster knob to suit the load or the road surface. Turn clockwise to increase spring preload (hard), or turn counterclockwise to decrease spring preload (soft). The standard position is 7 clicks from the minimum setting.



Adjuster knob

**I Rebound Damping**

You can adjust the rebound damping by the adjuster to suit the load or the road surface. Turn clockwise to increase rebound damping (hard), or turn counterclockwise to decrease rebound damping (soft). The standard position is 1 1/4 turns from the maximum setting so that the punch mark on the adjuster aligns with the reference punch mark.



## Other Adjustments ▶ Adjusting the Headlight Aim

### NOTICE

Do not turn the adjuster beyond its limits.


### NOTICE

The rear shock absorber damper unit contains high pressure nitrogen gas. Do not attempt to disassemble, service, or improperly dispose of the damper. See your dealer.

## Adjusting the Headlight Aim

You can adjust vertical aim of the headlight for proper alignment. Turn the knob in or out as necessary.

Obey local laws and regulations.



## Other Adjustments ▶ Changing the Front Seat Height

### Changing the Front Seat Height

The front seat can be changed to one of two positions according to your preference. To change the seat height, use the proper hex wrench.

In the interest of safety, we recommend that you have your dealer perform the adjustment.

1. Remove the front seat. ▶ P. 69
2. Remove the socket bolts A and seat adjust plates.
3. Move the adjust plates and install the socket bolts A in the mounting holes for your preferred seat position (high or low), and then tighten them.


**Torque:** 22 N·m (2.2 kgf·m, 16 lbf·ft).

4. If you change the front seat height from high position to low position, remove the socket bolts B/set collars A and socket bolt C/set collar B from the seat rail and front stay. (The socket bolts B/set collars A and socket bolt C/set collar B are not required for the low position.)

▶ Make sure to install the socket bolts B/set collars A and socket bolt C/set collar B when the seat height is returned to the high position. Tighten the socket bolts B and socket bolt C if reinstalling.

**Torque:** 12 N·m (1.2 kgf·m, 9 lbf·ft).


## Other Adjustments ▶ Changing the Front Seat Height



### 5. Install the front seat. ▶ P. 69

#### ▶ When setting the high seat position:

Install the front seat by aligning its recesses with the front side stays and placing its prong on the front centre stay.




Maintenance

continued 95


## Other Adjustments ▶ Changing the Front Seat Height

### ▶ When setting the low seat position:

Install the front seat by aligning its recesses with the front side stays and its prong with the front centre stay.



6. Make sure that the mount positions of the front seat prong and the adjust plates are the same seat position.



# Troubleshooting

<b>Engine Will Not Start (HISS indicator stays on)</b> .....	P. 98
<b>Overheating (High coolant temperature indicator is on)</b> .....	P. 99
<b>Warning Indicators On or Flashing</b> .....	P. 100
Low Oil Pressure Indicator .....	P. 100
PGM-FI (Programmed Fuel Injection) Malfunction Indicator Lamp (MIL).....	P. 100
ABS (Anti-lock Brake System) Indicator....	P. 101
Torque Control Indicator .....	P. 102
<b>Other Warning Indications</b> .....	P. 103
Fuel Gauge Failure Indications .....	P. 103
Handle Grip Heater Failure Indication.....	P. 103
<b>Tyre Puncture</b> .....	P. 104
<b>Electrical Trouble</b> .....	P. 111
Battery Goes Dead .....	P. 111
Burned-out Light Bulb .....	P. 111
Blown Fuse.....	P. 114

## Engine Will Not Start (HISS indicator stays on)

### I Starter Motor Operates But Engine Does Not Start

Check the following items:

- Check the correct engine starting sequence. ▣ P. 45
- Check that there is petrol in the fuel tank.
- Check if the PGM-FI malfunction indicator lamp (MIL) is on.
  - ▶ If the indicator light is on, contact your dealer as soon as possible.
- Check if the HISS indicator stays on.
  - ▶ Turn the ignition switch to the OFF position and remove the key. Reinsert the key and turn the ignition switch to the ON position. If the indicator still stays on, check the following:  
Check if there is no another HISS key (including spare key) close to the ignition switch.

Check if there are no any metallic seals or stickers on the key.

If the HISS indicator still stays on, have your motorcycle inspected by your dealer.

### I Starter Motor Does Not Operate

Check the following items:

- Make sure engine stop switch is  (Run) position. ▣ P. 38
- Make sure the side stand is raised.
- Check for a blown fuse. ▣ P. 114
- Check for a loose battery connection or battery terminal corrosion. ▣ P. 74
- Check the condition of the battery.  
▣ P. 111

If the problem continues, have your motorcycle inspected by your dealer.

## Overheating (High coolant temperature indicator is on)

The engine is overheating when the following occurs:

- High coolant temperature indicator comes on.
- Acceleration becomes sluggish.

If this occurs, pull safely to the side of the road and perform the following procedure. Extended fast idling may cause the high coolant temperature indicator to come on.

### NOTICE

Continuing to ride with an overheated engine can cause serious damage to the engine.

1. Stop the engine using the ignition switch, and then turn the ignition switch to the ON position.

2. Check that the radiator fan is operating, and then turn the ignition switch to the OFF position.

**If the fan is not operating:**

Suspect a fault. Do not start the engine. Transport your motorcycle to your dealer.

**If the fan is operating:**

Allow the engine to cool with the ignition switch in the OFF position.

3. After the engine has cooled, inspect the radiator hose and check if there is a leak.

➡ P. 79

**If there is a leak:**

Do not start the engine. Transport your motorcycle to your dealer.

4. Check the coolant level in the reserve tank, and add coolant as necessary.  
➡ P. 79
5. If 1-4 check normal, you may continue riding, but closely monitor the temperature gauge.

## Warning Indicators On or Flashing

### Low Oil Pressure Indicator

If the low oil pressure indicator comes on, pull safely to the side of the road and stop the engine.

#### NOTICE

Continuing to ride with low oil pressure can cause serious damage to the engine.

1. Check the engine oil level, and add oil as necessary.  P. 75
2. Start the engine.
  - ▶ Only continue riding if the low oil pressure indicator goes off.

Rapid acceleration may momentarily cause the low oil pressure indicator to come on, especially if the oil is at or near the low level. If the low oil pressure indicator stays on when the oil level is at the proper level, stop the engine and contact your dealer.

If the engine oil level goes down rapidly, your motorcycle may have a leak or another serious problem. Have your motorcycle inspected by your dealer.

### PGM-FI (Programmed Fuel Injection) Malfunction Indicator Lamp (MIL)

If the indicator comes on while riding, you may have a serious problem with the PGM-FI system. Reduce speed and have your motorcycle inspected by your dealer as soon as possible.

## Warning Indicators On or Flashing ► ABS (Anti-lock Brake System) Indicator

### ABS (Anti-lock Brake System) Indicator

If the indicator operates in one of the following ways, you may have a serious problem with the brake system. Reduce your speed and have your motorcycle inspected by your dealer as soon as possible.

- Indicator comes on or starts flashing while riding.
- Indicator does not come on when the ignition switch is in the ON position.
- Indicator does not go off at speeds above 10 km/h (6 mph).

If the ABS indicator stays on, your brakes will continue to work as a conventional system, but without the anti-locking function.

The ABS indicator may flash if you turn the rear wheel while your motorcycle is lifted off the ground. In this case, turn the ignition switch off and then on again. The ABS indicator will go off after your speed reaches 30 km/h (19 mph).

## Warning Indicators On or Flashing ► Torque Control Indicator

### Torque Control Indicator

If the indicator operates in one of the following ways, you may have a serious problem with the Torque Control. Reduce your speed and have your motorcycle inspected by your dealer as soon as possible.

- Indicator comes and stays on (solid) while riding.
- Indicator does not come on when the ignition switch is turned on.
- Indicator does not go off at speeds above 10 km/h (6 mph).

Even when the Torque Control indicator is on, your motorcycle will have normal riding ability without Torque Control function.

- When the indicator comes on while the Torque Control is in operation, you will have to completely close the throttle to regain normal riding ability.



The Torque Control indicator may come on if you rotate the rear wheel while your motorcycle is lifted off the ground. In this case, turn the ignition switch off and on again. The Torque Control indicator will go off after your speed reaches 10 km/h (6 mph).

## Other Warning Indications

### Fuel Gauge Failure Indications


If the fuel system has an error, the fuel gauge indicators will be displayed as shown in the illustration.

If this occurs, see your dealer as soon as possible.



### Handle Grip Heater Failure Indication

If the handle grip heater system has an error, the handle grip heater status icon will blink. If the "E1", "E2" or "E3" blinking does not go off, see your dealer as soon as possible.



## Tyre Puncture

Repairing a puncture or removing a wheel requires special tools and technical expertise. We recommend you have this type of service performed by your dealer. After an emergency repair, always have the tyre inspected/replaced by your dealer.

### Troubleshooting

## Emergency Repair Using a Tyre Repair Kit

If your tyre has a minor puncture, you can make an emergency repair using a tubeless tyre repair kit.

Follow the instructions provided with the emergency tyre repair kit.

Riding your motorcycle with a temporary tyre repair is very risky. Do not exceed 50 km/h (30 mph). Have the tyre replaced by your dealer as soon as possible.

## **⚠ WARNING**

Riding your motorcycle with a temporary tyre repair can be risky. If the temporary repair fails, you can crash and be seriously injured or killed.

If you must ride with a temporary tyre repair, ride slowly and carefully and do not exceed 50 km/h (30 mph) until the tyre is replaced.

## Removing Wheels


Follow these procedures if you need to remove a wheel in order to repair a puncture.

When removing and installing the wheel, be careful not to damage the wheel speed sensor and pulser ring.

## Front Wheel

### Removal

1. Place your motorcycle on a firm, level surface.
2. Cover both sides of the front wheel and brake caliper with protective tape or cloth.



### Tyre Puncture ▶ Removing Wheels

3. Remove the wheel speed sensor by removing the bolts.
4. On the right side, remove the mounting bolts and remove the brake caliper.
5. On the left side, remove the mounting bolts and remove the brake caliper.
  - ▶ Support the brake caliper assembly so that it doesn't hang from the brake hose. Do not twist the brake hose.
  - ▶ Avoid getting grease, oil, or dirt on the disc or pad surfaces.
  - ▶ Do not pull the brake lever while the brake caliper is removed.
  - ▶ Take care to prevent the brake caliper from scratching the wheel during removal.



Troubleshooting

continued 105

## Tyre Puncture ► Removing Wheels


6. Remove the front axle bolt.
7. Loosen the right axle pinch bolts.
8. Support your motorcycle securely and raise the front wheel off the ground using a maintenance stand or a hoist.
9. Loosen the left axle pinch bolts.
10. On the left side, withdraw the front axle shaft, and remove the side collars and wheel.

Troubleshooting



## Installation

1. Attach the side collars to the wheel.
2. On the left side, place the wheel between the fork legs and insert the lightly greased front axle shaft to the end, through the left fork leg and wheel hub.
3. Align the end of the front axle shaft with the surface of the fork leg.



## Tyre Puncture ► Removing Wheels

4. Tighten the left axle pinch bolts to hold the axle.

5. Tighten the axle bolt.

**Torque:** 59 N·m (6.0 kgf·m, 44 lbf·ft).

6. Loosen the left axle pinch bolts.

7. Tighten the right axle pinch bolts.

**Torque:** 22 N·m (2.2 kgf·m, 16 lbf·ft).

8. Install the right brake caliper and tighten the mounting bolts.

**Torque:** 45 N·m (4.6 kgf·m, 33 lbf·ft).

Troubleshooting

continued 107

## Tyre Puncture ► Removing Wheels

9. Install the left brake caliper and tighten the mounting bolts.

**Torque:** 45 N·m (4.6 kgf·m, 33 lbf·ft).

- Take care to prevent the brake caliper from scratching the wheel during installation.
- Use new mounting bolts when installing the brake caliper.

### NOTICE

When installing the brake calipers into position on the fork legs, carefully fit the brake disc between the pads to avoid scratching them.

10. Lower the front wheel on the ground.
11. Apply the brake lever and brake pedal several times. Then, pump the fork several times.
12. Retighten the left axle pinch bolts.

**Torque:** 22 N·m (2.2 kgf·m, 16 lbf·ft).

13. Raise the front wheel off the ground again, and check that the wheel rotates freely after you release the brake.
14. Install the wheel speed sensor and tighten the bolts, then check the clearance between the wheel speed sensor and the pulser ring.
15. Remove the protective tape or cloth.


If a torque wrench was not used for installation, see your dealer as soon as possible to verify proper assembly. Improper assembly may lead to loss of braking capacity.

## Tyre Puncture ▶ Removing Wheels


### Rear Wheel

#### Removal

1. Support your motorcycle securely and raise the rear wheel off the ground using a maintenance stand or a hoist.
2. Loosen the muffler band bolts.
3. Remove the muffler stay bolt, nut and washer.



4. Move the muffler outward.
5. Remove the rear wheel nuts, and remove the rear wheel.



Troubleshooting

## Tyre Puncture ► Removing Wheels

### Installation

1. To install the rear wheel, reverse the removal procedure.
2. Tighten the rear wheel nuts equally.

**Torque:** 108 N·m (11.0 kgf·m, 80 lbf·ft).

3. Hold the muffler mounting bolt and tighten the mounting nut.

**Torque:** 27 N·m (2.8 kgf·m, 20 lbf·ft).

4. Tighten the muffler band bolts.

**Torque:** 21 N·m (2.1 kgf·m, 15 lbf·ft).

5. Check that the wheel rotates freely.

If a torque wrench was not used for installation, see your dealer as soon as possible to verify proper assembly. Improper assembly may lead to loss of braking capacity.

Troubleshooting

## Electrical Trouble

### Battery Goes Dead

Charge the battery using a motorcycle battery charger.

Remove the battery from the motorcycle before charging.

Do not use an automobile-type battery charger, as these can overheat a motorcycle battery and cause permanent damage.

If the battery does not recover after recharging, contact your dealer.

#### NOTICE

Jump starting using an automobile battery is not recommended, as this can damage your motorcycle's electrical system.

### Burned-out Light Bulb

Follow the procedure below to replace a burned-out light bulb.

Turn the ignition switch to the OFF or LOCK position.

Allow the bulb to cool before replacing it.


Do not use bulbs other than those specified.

Check the replacement bulb for correct operation before riding.

For the light bulb wattage, see "Specifications". ➤ P. 132


Electrical Trouble ▶ Burned-out Light Bulb

## Headlight



The headlight uses several LEDs.  
If there is a LED which is not turned on, see  
your dealer for this service.


## Brake/Tail light



The brake and tail light uses several LEDs.  
If there is a LED which is not turned on, see  
your dealer for this service.

Troubleshooting

## Front/Rear Turn Signal Light




The front and rear turn signal lights use several LEDs.  
If there is a LED which is not turned on, see your dealer for this service.

## Electrical Trouble ▶ Burned-out Light Bulb

### License Plate Light

1. Remove the screws.
2. Remove the license light cover and license light cover packing.
3. Pull out the bulb without turning.




4. Install a new bulb and parts in the reverse order of removal.

Electrical Trouble ► Blown Fuse

## Blown Fuse

Before handling fuses, see “Inspecting and Replacing Fuses”. ▣ P. 59

### I Fuse Box Fuses




Troubleshooting

1. Remove the battery cover. ▣ P. 72
2. Open the fuse box covers.
3. Pull the fuses out with the fuse puller in the tool kit and check for a blown fuse. Always replace a blown fuse with a spare of the same rating.
4. Close the fuse box covers.
5. Reinstall the battery cover.

## Electrical Trouble ▶ Blown Fuse

### I Main Fuse & FI Fuse



1. Remove the battery cover. ▶ P. 72
2. Remove the starter magnetic switch cover.

3. Pull the main fuse and FI fuse out with the fuse puller in the tool kit and check for a blown fuse. Always replace a blown fuse with a spare of the same rating.
  - ▶ Spare fuses are provided in the fuse box.
4. Reinstall parts in the reverse order of removal.

#### NOTICE

If a fuse fails repeatedly, you likely have an electrical problem. Have your motorcycle inspected by your dealer.

# Information

<b>Keys</b> .....	P. 117
<b>Instruments, Controls, &amp; Other Features</b> ..	P. 118
<b>Fuels Containing Alcohol</b> .....	P. 121
<b>Catalytic Converter</b> .....	P. 122
<b>Caring for Your Motorcycle</b> .....	P. 123
<b>Storing Your Motorcycle</b> .....	P. 126
<b>Transporting Your Motorcycle</b> .....	P. 127
<b>You &amp; the Environment</b> .....	P. 128
<b>Serial Numbers</b> .....	P. 129

## Keys

### Ignition key

This motorcycle has two ignition keys and a key tag with a key number and a bar code.

The ignition key contains a special coded chip that is recognized by the immobilizer system (HISS) in order to start the engine. Handle the key carefully to prevent damaging the HISS components.

- Do not bend keys or subject them to undue stress.
- Avoid prolonged exposure to sunlight or high temperatures.
- Do not grind, drill or in any way alter their shape.
- Do not expose to strong magnetic objects.

If you lose all keys and the key tag, the PGM-FI unit/ignition control module must be replaced by your dealer. To avoid this, keep a duplicate


key.

If you lose a key, make another duplicate key immediately.

To make a duplicate key and register it with your HISS system, take the spare key, the key tag, and the motorcycle to your dealer.

► Store the tag in a safe location.

A metal key holder may cause damage to the area surrounding the ignition switch.



Information

Keys

## Instruments, Controls, & Other Features

# Instruments, Controls, & Other Features

### Ignition Switch

The headlight is always on when the ignition switch is ON. Leaving the ignition switch on with the engine stopped will drain the battery. Do not turn the key while riding.

### Engine Stop Switch

Do not use the engine stop switch except in an emergency. Doing so when riding will cause the engine to suddenly turn off, making riding unsafe.

If you stop the engine using the engine stop switch, turn the ignition switch off. Failing to do so will drain the battery.

### Odometer

The display locks at 999,999 when the readout exceeds 999,999.

### Tripmeter

The tripmeter A, B returns to 0.0 when the readout exceeds 9,999.9.

### HISS

The Honda Ignition Security System (HISS) immobilizes the engine's ignition system if an improperly-coded key is used to try and start the engine. When the ignition switch is turned off, the HISS immobilizer system is always alert, even if the HISS indicator is not flashing.

If the ignition switch is turned on with the engine stop switch in the  (Run) position, the HISS indicator turns on and goes off after a few seconds to indicate it is OK to start the engine.

**HISS Indicator Does Not Turn off P. 98**

The HISS indicator starts flashing every 2 seconds for 24 hours after the ignition switch is turned off. You can turn this feature on or off.

▶ P. 33

### EC Directive

This immobilizer system complies with R & TTE (Radio and Telecommunications Terminal Equipment and the mutual recognition of their conformity) Directive.

## Instruments, Controls, & Other Features



The declaration of conformity to R & TTE Directive is provided to the owner at the time of purchase. The declaration of conformity should be kept at a safe place. When the declaration of conformity is lost or is not provided, contact your dealer.


### South Africa only



### Singapore only



### Morocco only



Information

continued 119

## Instruments, Controls, & Other Features

### Document Bag

The owner's manual, registration, and insurance information can be stored in the plastic document bag located under the front seat.

### Ignition Cut-off System

A banking (lean angle) sensor automatically stops the engine and fuel pump if the motorcycle falls over. To reset the sensor, you must turn the ignition switch to OFF and back to the ON position before the engine can be restarted.

Information

## Fuels Containing Alcohol

Some conventional fuels blended with alcohol are available in some locales to help reduce emissions to meet clean air standards. If you plan to use blended fuel, check that it is unleaded and meets the minimum octane rating requirement.

The following fuel blends can be used in your motorcycle:

- Ethanol (ethyl alcohol) up to 10 % by volume.
  - ▶ Petrol containing ethanol may be marketed under the name Gasohol.

## Fuels Containing Alcohol

The use of petrol containing more than 10 % ethanol may:

- Damage the painting of the fuel tank.
- Damage the rubber tubes of the fuel line.
- Cause corrosion of the fuel tank.
- Cause poor drivability.

### NOTICE

Use of blended fuels containing higher than approved percentages can damage metal, rubber, plastic parts of your fuel system.

If you notice any undesirable operating symptoms or performance problems, try a different brand of petrol.

## Catalytic Converter

# Catalytic Converter

This motorcycle is equipped with a three-way catalytic converter. The catalytic converter contains precious metals that serve as catalysts in high temperature chemical reactions that convert hydrocarbons (HC), carbon monoxide (CO), and oxides of nitrogen (NOx) in the exhaust gasses into safe compounds.

### Information

A defective catalytic converter contributes to air pollution and can impair your engine's performance. A replacement unit must be an original Honda part or equivalent.

Follow these guidelines to protect your motorcycle's catalytic converter.

- Always use unleaded petrol. Leaded petrol will damage the catalytic converter.
- Keep the engine in good running condition.
- Have your motorcycle serviced if your engine is misfiring, backfiring, stalling, or otherwise not running properly, stop riding and turn off the engine.

## Caring for Your Motorcycle

Frequent cleaning and polishing is important to ensure the life of your Honda. A clean motorcycle makes it easier to spot potential problems.

In particular, seawater and salts used to prevent ice on roads promote the formation of corrosion. Always wash your motorcycle thoroughly after riding on coastal or treated roads.

### Washing

Allow the engine, muffler, brakes, and other high-temperature parts to cool before washing.

1. Rinse your motorcycle thoroughly using a garden hose to remove loose dirt.
2. If necessary, use a sponge or a soft towel with mild cleaner to remove road grime.
  - ▶ Clean the windscreen, headlight lens, panels, and other plastic components with extra care to avoid scratching them.

## Caring for Your Motorcycle

Avoid directing water into the air cleaner, muffler, and electrical parts.

3. Thoroughly rinse your motorcycle with plenty of clean water and dry with a soft, clean cloth.
4. After the motorcycle dries, lubricate any moving parts.
  - ▶ Make sure that no lubricant spills onto the brakes or tyres. Brake discs, pads, drum or shoes contaminated with oil will suffer greatly reduced braking effectiveness and can lead to a crash.
5. Lubricate the drive chain immediately after washing and drying the motorcycle.
6. Apply a coat of wax to prevent corrosion.
  - ▶ Avoid products that contain harsh detergents or chemical solvents. These can damage the metal, paint, and plastic on your motorcycle.Keep the wax clear of the tyres and brakes.

## Caring for Your Motorcycle

- ▶ If your motorcycle has any mat painted parts, do not apply a coat of wax to the mat painted surface.

### Washing Precautions

Follow these guidelines when washing:

- Do not use high-pressure washers:
  - ▶ High-pressure water cleaners can damage moving parts and electrical parts, rendering them inoperable.
- Do not direct water at the muffler:
  - ▶ Water in the muffler can prevent starting and causes rust in the muffler.
- Dry the brakes:
  - ▶ Water adversely affects braking effectiveness. After washing, apply the brakes intermittently at low speed to help dry them.
- Do not direct water under the seat:
  - ▶ Water in the underseat compartment can damage your documents and other belongings.

- Do not direct water at the air cleaner:
  - ▶ Water in the air cleaner can prevent the engine from starting.
- Do not direct water near the headlight:
  - ▶ Any condensation inside the headlight should dissipate after a few minutes of running the engine.
- Do not use waxes containing compounds at the mat painted surface:
  - ▶ Using plenty of water, clean the mat painted surface with a soft cloth or sponge. Dry with a soft, clean cloth.
  - ▶ Use neutral detergent to clean mat painted surface.

## Caring for Your Motorcycle

### Aluminium Components

Aluminium will corrode from contact with dirt, mud, or road salt. Clean aluminium parts regularly and follow these guidelines to avoid scratches:

- Do not use stiff brushes, steel wool, or cleaners containing abrasives.
- Avoid riding over or scraping against curbs.

### Panels

Follow these guidelines to prevent scratches and blemishes:

- Wash gently using a soft sponge and plenty of water.
- To remove stubborn stains, use diluted detergent and rinse thoroughly with plenty of water.
- Avoid getting petrol, brake fluid, or detergents on the instruments, panels, or headlight.

### Windscreen

Using plenty of water, clean the windscreen with a soft cloth or sponge. (Avoid using detergents or any kind of chemical cleaner on the windscreen.) Dry with a soft, clean cloth.

#### NOTICE

To avoid possible scratching or other damage, use only water and a soft cloth or sponge to clean the windscreen.

For a dirtier windscreen, use a diluted neutral detergent with a sponge and plenty of water. Make sure to wash off all the detergent. (Detergent residue may cause windscreen cracks.)

Replace the windscreen if scratches cannot be removed and they obstruct clear vision.

Take care to keep battery electrolyte, brake fluid, or other chemical solvents off the windscreen and screen garnish. They will damage the plastic.

Information

continued 125

## Storing Your Motorcycle

### Exhaust Pipe and Muffler

The exhaust pipe and muffler are stainless steel but may become stained by mud or dust.

To remove mud or dust, use a wet sponge and a liquid kitchen abrasive, then rinse well with clean water. Dry with chamois or a soft towel. If necessary, remove heat stains by using a commercially available fine texture compound. Then rinse by the same manner as removing mud or dust.

#### NOTICE

Even though the exhaust is made of stainless steel, it can become stained. Remove all marks and blemishes as soon as they are noticed.

Information

## Storing Your Motorcycle

If you store your motorcycle outdoors, you should consider using a full-body motorcycle cover.

If you won't be riding for an extended period, follow these guidelines:

- Wash your motorcycle and wax all painted surfaces (except mat painted surfaces).  
Coat chrome pieces with rust-inhibiting oil.
- Lubricate the drive chain.  P. 62
- Place your motorcycle on a maintenance stand and position a block so that both tyres are off the ground.
- After rain, remove the body cover and allow the motorcycle to dry.
- Remove the battery ( P. 74) to prevent discharge. Charge the battery in a shaded, well-ventilated area.
  - ▶ If you leave the battery in place, disconnect the negative  $\ominus$  terminal to prevent discharge.

After removing your motorcycle from storage, inspect all maintenance items required by the Maintenance Schedule.

## Transporting Your Motorcycle

### Transporting Your Motorcycle

If your motorcycle needs to be transported, it should be carried on a motorcycle trailer or a flatbed truck or trailer that has a loading ramp or lifting platform, and motorcycle tie-down straps. Never try to tow your motorcycle with a wheel or wheels on the ground.

#### NOTICE

Towing your motorcycle can cause serious damage to the transmission.

Information

## You & the Environment

# You & the Environment

Owning and riding a motorcycle can be enjoyable, but you must do your part to protect the environment.

### Choose Sensible Cleaners

Use a biodegradable detergent when you wash your motorcycle. Avoid aerosol spray cleaners that contain chlorofluorocarbons (CFCs) which damage the atmosphere's protective ozone layer.

### Recycle Wastes

Put oil and other toxic wastes in approved containers and take them to a recycling centre. Call your local or state office of public works or environmental services to find a recycling centre in your area, and to get instructions on how to dispose of non-recyclable wastes. Do not place used engine oil in the trash, or pour it down a

drain or on the ground. Used oil, petrol, coolant, and cleaning solvents contain poisons that can hurt refuse workers and contaminate drinking water, lakes, rivers, and oceans.



## Serial Numbers

### Serial Numbers

The frame and engine serial numbers uniquely identify your motorcycle and are required in order to register your motorcycle. They may also be required when ordering replacement parts. The frame number is stamped on the right side of the steering head.

The engine number is stamped on top of the crankcase.

You should record these numbers and keep them in a safe place.



Information

## Specifications

### ■ Main Components

Type	RC80
Overall length	2,190 mm (86.2 in)
Overall width	870 mm (34.3 in)
Overall height	1,360 mm (53.5 in)
Wheelbase	1,475 mm (58.1 in)
Minimum ground clearance	165 mm (6.5 in)
Caster angle	26° 30'
Trail	103 mm (4.1 in)
Curb weight	242 kg (534 lb)
Maximum weight capacity*1	192 kg (423 lb)
Maximum luggage weight*2	18 kg (40 lb)
Passenger capacity	Rider and 1 passenger
Minimum turning radius	2.4 m (7.9 ft)

\*1 Including rider, passenger, all luggage, and accessories

\*2 Includes the weight of the luggage and added accessories.

Displacement	782 cm <sup>3</sup> (47.7 cu-in)
Bore x stroke	72.0 x 48.0 mm (2.83 x 1.89 in)
Compression ratio	11.8 : 1
Fuel	Unleaded petrol Recommended: 91 RON or higher
Tank capacity	20.8 litres (5.50 US gal, 4.58 Imp gal)
Battery	YTZ12S 12V-11Ah (10 HR) / 11.6Ah (20 HR)
Gear ratios	1st 2.846
	2nd 2.062
	3rd 1.578
	4th 1.291
	5th 1.111
	6th 0.965
Reduction ratios (primary / final)	1.939 / 2.687

## Specifications

### ■ Service Data

Tyre size	Front	120/70R17M/C 58V
	Rear	180/55R17M/C 73V
Tyre type		Radial, tubeless
Recommended Tyres	Front	PIRELLI SCORPION TRAIL
	Rear	PIRELLI SCORPION TRAIL
Tyre air pressure	Front	250 kPa (2.50 kgf/cm <sup>2</sup> , 36 psi)
	Rear	290 kPa (2.90 kgf/cm <sup>2</sup> , 42 psi)
Minimum tread depth	Front	1.5 mm (0.06 in)
	Rear	2.0 mm (0.08 in)
Spark plugs	(standard)	IMR9D-9H (NGK) or VNH27ZB (DENSO)
Spark plug gap	(non-adjustable)	0.80 to 0.90 mm (0.031 to 0.035 in)
Idle speed		1,200 ± 100 rpm
Recommended engine oil		Honda 4-stroke motorcycle oil API Service Classification SG or higher, excluding oils marked as "Energy Conserving" or "Resource Conserving," SAE 10W-30, JASO T 903 standard MA

Engine oil capacity	After draining	2.9 litres (3.1 US qt, 2.6 Imp qt)
	After draining & engine oil filter change	3.1 litres (3.3 US qt, 2.7 Imp qt)
	After disassembly	3.9 litres (4.1 US qt, 3.4 Imp qt)
Recommended brake (clutch) fluid	Honda DOT 4 Brake Fluid	
Cooling system capacity	2.42 litres (2.56 US qt, 2.13 Imp qt)	
Recommended coolant	Pro Honda HP Coolant	

## Specifications

Recommended drive chain lubricant	Drive chain lubricant designed specifically for O-ring chains. If not available, use SAE 80 or 90 gear oil.	
Drive chain slack	30 to 40 mm (1.2 to 1.6 in)	
Standard drive chain	DID 525HV3 or RK 525ROZ6	
	No. of links	110
Standard sprocket sizes	Engine sprocket	16T
	Rear wheel sprocket	43T

### ■ Bulbs

Headlight	LED
Brakelight	LED
Tail light	LED
Front turn signal lights	LED
Rear turn signal lights	LED
License plate light	12V-5W

### ■ Fuses

Main fuse	30A
Other fuses	30A, 20A, 10A

## ■ Torque Specifications

Engine oil drain bolt	30 N·m (3.1 kgf·m, 22 lbf·ft)
Oil filter	26 N·m (2.7 kgf·m, 19 lbf·ft)
Bearing holder pinch bolt	74 N·m (7.5 kgf·m, 55 lbf·ft)
Seat adjust plate socket bolts A	22 N·m (2.2 kgf·m, 16 lbf·ft)
Seat adjust set collar socket bolts B/socket bolt C	12 N·m (1.2 kgf·m, 9 lbf·ft)
Front wheel axle bolt	59 N·m (6.0 kgf·m, 44 lbf·ft)
Front wheel brake caliper mounting bolts	45 N·m (4.6 kgf·m, 33 lbf·ft)
Front wheel axle pinch bolts	22 N·m (2.2 kgf·m, 16 lbf·ft)
Rear wheel nuts	108 N·m (11.0 kgf·m, 80 lbf·ft)
Muffler mounting nut	27 N·m (2.8 kgf·m, 20 lbf·ft)
Muffler band bolts	21 N·m (2.1 kgf·m, 15 lbf·ft)

## Index

### A

ABS (Anti-lock Brake System)	
Indicator .....	37, 101
Accessories.....	16
Anti-lock Brake System (ABS).....	13

### B

Battery .....	58, 74
Battery Cover .....	72
Brakelight Switch.....	83
Brakes	

Fluid.....	61, 81
Lever Adjustment .....	89
Pad Wear.....	82

Braking .....	12
---------------	----

### Bulb

Brake/Tail Light .....	112
Front/Rear Turn Signal.....	113
Headlight.....	112
License Plate Light.....	113

### C

Caring for Your Motorcycle.....	123
Clutch	
Fluid.....	61, 83
Lever Adjustment .....	89
Colour Label .....	57
Compartment	
Owner's Manual.....	120
Coolant .....	62, 79

### D

Digital Clock Adjustment.....	31
Display Setting.....	30
Drive Chain .....	85

**E**

Electrical Trouble..... 111

**Engine**

Number..... 129

Oil..... 60, 75

Oil Filter..... 77

Overheats..... 99

Starting..... 45

Stop Switch..... 39, 45, 118

Stopping..... 118

Environment..... 128

**Equipment Compartment**

Helmet Holder..... 48

Owner's Manual..... 49, 120

Tool Kit..... 49

U-shaped Lock..... 49

**F**

Flooded Engine..... 45

Frame Number..... 129

Front Brake Lever Adjustment..... 89

Front Seat..... 69

Front Seat Height Adjustment..... 94

**Fuel**

Gauge..... 21

Mileage Meter..... 25

Recommended..... 47

Remaining..... 21

Tank Capacity..... 47

Fuels Containing Alcohol..... 121

Fuses..... 59, 114

**G**

Gear Position Indicator..... 24

**H**

Handle Grip Heater..... 29, 41, 103

Handle Grip Heater Indicator..... 38, 41

Handle Grip Heater Status Icon..... 21, 41

Hazard Switch..... 39

Headlight Aim..... 93

Headlight Dimmer Switch..... 38

Helmet Holder..... 48

High Beam Indicator..... 36

High Coolant Temperature

Indicator..... 37, 99

HISS Indicator ..... 30, 37, 98  
 Horn Button ..... 39

**I**

**Ignition Cut-off System**

Banking Sensor ..... 120  
 Side Stand ..... 84  
 Ignition key ..... 117  
 Ignition Switch ..... 39, 45, 118

Image Labels ..... 6  
 Indicators ..... 36  
 Instruments ..... 20

**L**

Labels ..... 6  
 Load Limits ..... 17  
 Loading Guidelines ..... 17  
 Low fuel Indicator ..... 36  
 Low Oil Pressure Indicator ..... 36, 100

**M**

**Maintenance**

Fundamentals ..... 56

Importance ..... 52  
 Safety ..... 52  
 Schedule ..... 53  
**Maximum Weight Limit** ..... 17  
**Modifications** ..... 16

**N**

Neutral Indicator ..... 36

**O**

Odometer ..... 23, 118  
 Oil  
     Engine ..... 60, 75  
**Overheating** ..... 99

**P**

Parking ..... 14  
 Parts Location ..... 18  
 Passing light control switch ..... 38  
 Petrol ..... 47  
**PGM-FI (Programmed Fuel Injection)**  
     Malfunction Indicator Lamp (MIL) .... 36, 100  
**Protective Apparel** ..... 11

<b>R</b>		<b>Specifications</b> .....	130
Rear Seat.....	68	Speedometer.....	21
<b>Recommended</b>		Start Button .....	39, 45
Coolant.....	62	<b>Starting the Engine</b> .....	45
Fuel .....	47	Steering Lock .....	40
Oil.....	60	Stopping Engine .....	118
Refuelling .....	47	<b>Storage</b>	
<b>Removal</b>		Document Bag.....	49
Battery .....	74	Equipment.....	48
Battery Cover .....	72	Helmet.....	48
Front Seat.....	69	Owner's Manual .....	49
Rear Seat.....	68	Tool Kit.....	49
Right Under Cover.....	71	U-shaped Lock .....	49
Repair Kit.....	104	<b>Storing Your Motorcycle</b> .....	126
Riding Precautions .....	12	Switches.....	38
Right Under Cover.....	71		
		<b>T</b>	
<b>S</b>		Tachometer .....	20
Safety Precautions.....	11	Throttle .....	88
Serial Numbers .....	129	Tool Kit.....	49, 50, 67
Shifting Gears .....	46	Torque Control .....	15, 43
Side Stand .....	84	Torque Control Indicator .....	37, 102
Side Stand Ignition Cut-off System .....	84	Torque Control OFF Indicator .....	37

Transporting Your Motorcycle.....	127
Tripmeter.....	23
Troubleshooting .....	97
Turn Signal Indicators.....	36, 37
Turn signal switch .....	38
<b>Tyres</b>	
Air Pressure.....	64
Puncture .....	104
Replacing .....	64, 104
<b>W</b>	
Warning Indicators On .....	99, 100
Washing Your Motorcycle.....	123
Weight Limit .....	17
<b>Wheels</b>	
Front Removal.....	105
Rear Removal .....	109

